

DMX Channel Table

8 Channel mode			
Channel	Name	DMX Value	Description
1	Tilt	0-255	Tilt Movemnt
2	Beam Dimmer	0-255	Tube Strobe Intensity
3	Beam Mode	0-5	No Strobe
		6-42	Strobe Mode 1
		43-85	Strobe Mode 1
		86-128	Strobe Mode 1
		129-171	Strobe Mode 1
		172-214	Strobe Mode 1
		215-255	Strobe Mode 1
4	RGB Dimmer	0-255	0-100%
5	Plate Red	0-255	Plate Red Dimmer
6	Plate Green	0-255	Plate Green Dimmer
7	Plate Blue	0-255	Plate Blue Dimmer
8	Plate Strobe	0-9	No Strobe
		10-255	Strobe from slow to fast

15 Channel mode			
Channel	Name	DMX Value	Description
1	Tilt	0-255	Tilt Movemnt
2	Tilt Fine	0-007	Tilt Fine Movemnt
3	Beam Dimmer	0-255	Tube Strobe Intensity
4	Beam Mode	0-5	No Strobe
		6-42	Strobe Mode 1
		43-85	Strobe Mode 1
		86-128	Strobe Mode 1
		129-171	Strobe Mode 1
		172-214	Strobe Mode 1
		215-255	Strobe Mode 1
5	Beam Duration	0-255	Tube Flash Duration 0~3s
6	Beam Macro	0-15	Tube Macro Off
		16-57	Tube Macro 1
		58-99	Tube Macro 2
		100-141	Tube Macro 3
		142-183	Tube Macro 4
		184-225	Tube Macro 5
		226-255	Tube Macro 6
7	RGB Dimmer	0-255	0-100%
8	Plate Red	0-255	Plate Red Dimmer
9	Plate Green	0-255	Plate Green Dimmer
10	Plate Blue	0-255	Plate Blue Dimmer
11	Plate Strobe	0-9	No Strobe
		10-255	Strobe from slow to fast
12	Plate Macro	0-4	Plate Macro Off
		5-9	Plate Macro 1
		10-14	Plate Macro 2
		15-19	Plate Macro 3
		...	Plate Macro ...
		250-254	Plate Macro 50
		255	Plate Macro 51
13	Plate Macro Color	0-255	Plate Macro Color
14	Plate Macro Speed	0-255	Speed from slow to fast
15	Reserved	0-255	Reserved Channel

43 Channel mode			
Channel	Name	DMX Value	Description
1	Tilt	0-255	Tilt Movemnt
2	Tilt Fine	0-007	Tilt Fine Movemnt
3	Beam Dimmer	0-255	Tube Strobe Intensity
4	Beam Mode	0-5	No Strobe
		6-42	Strobe Mode 1
		43-85	Strobe Mode 1
		86-128	Strobe Mode 1
		129-171	Strobe Mode 1
		172-214	Strobe Mode 1
		215-255	Strobe Mode 1
5	Beam Duration	0-255	Tube Flash Duration 0~3s
6	Beam Macro	0-15	Tube Macro Off
		16-57	Tube Macro 1
		58-99	Tube Macro 2
		100-141	Tube Macro 3
		142-183	Tube Macro 4
		184-225	Tube Macro 5
		226-255	Tube Macro 6
7	RGB Dimmer	0-255	0-100%
8	Plate Red	0-255	Plate Red Dimmer
9	Plate Green	0-255	Plate Green Dimmer
10	Plate Blue	0-255	Plate Blue Dimmer
11	Plate Strobe	0-9	No Strobe
		10-255	Strobe from slow to fast
12	Plate Macro	0-4	Plate Macro Off
		5-9	Plate Macro 1
		10-14	Plate Macro 2
		15-19	Plate Macro 3
		...	Plate Macro ...
		250-254	Plate Macro 50
		255	Plate Macro 51
13	Plate Macro Color	0-255	Plate Macro Color
14	Plate Macro Speed	0-255	Speed from slow to fast
15	Reserved	0-255	Reserved Channel
16	Beam Pixel 1	0-255	Tube Pixel 1
17	Beam Pixel 2	0-255	Tube Pixel 2
18	Beam Pixel 3	0-255	Tube Pixel 3
19	Beam Pixel 4	0-255	Tube Pixel 4
20	Plate Pixel 1 Red	0-255	Plate Pixel 1 Red Dimmer
21	Plate Pixel 1 Green	0-255	Plate Pixel 1 Green Dimmer
22	Plate Pixel 1 Blue	0-255	Plate Pixel 1 Blue Dimmer
...
41	Plate Pixel 8 Red	0-255	Plate Pixel 8 Red Dimmer
42	Plate Pixel 8 Green	0-255	Plate Pixel 8 Green Dimmer
43	Plate Pixel 8 Blue	0-255	Plate Pixel 8 Blue Dimmer