

#### **BLOWER6LED**

LED Confetti Blower

#### **USER MANUAL**



### For safety, please read this user manual carefully before initial use.

Event Lighting reserves the right to revise the manual at any time. Information and specifications within this manual are subject to change without notice. Event Lighting assumes no liability or responsibility for any errors or omissions. Please consult Event Lighting for any clarification or information regarding this item.

Version: 1

## **Safety Instructions**

#### Warning

- Do not open this device, there are no user-serviceable parts inside.
- Do not look at the light source when the device is on.
- This unit's housing may be hot during and after operation.
- Install this device in a location with adequate ventilation, at least 50 cm (20 inches) from adjacent surfaces.
- Do not leave any flammable material within 50 cm of this unit while operating or connected to power.
- Do not operate this device outdoors or in any location where dust, excessive heat, water, or humidity may affect it.
- Do not operate this device if the housing, lenses, or cables appear damaged.
- Do not connect this device to a dimmer or rheostat.
- ONLY connect this device to a grounded and protected circuit.
- In case of a serious operating problem, stop using immediately.
- The maximum ambient temperature is 104° F (40° C). Do not operate this device at higher temperatures.

### **RF Remote**

BLOWER6LED can be controlled with an RF remote from up to 15 metres away.



## **DMX Chart**

- This fixture is controlled by the universal DMX 512 protocol. The DMX address is the first channel used to receive instructions from the external controller. For independent control, each fixture must be assigned a unique address for each of its control channels. For example, this device has one channel mode: 6, if it's set to 6 channel mode, and there are several fixtures need to be independently controlled, we just simply address first fixture at 1, and second fixture at 7, third one at 13, etc.
- If multiple fixtures have the same DMX address, they will behave synchronically.
- Display will flash when no DMX signal is received.

Channel	Min. DMX	Max. DMX	Function
1	0	255	Fan speed
2	0	255	LED Auto
3	0	255	Blue, 0-100%
4	0	255	Green, 0-100%
5	0	255	Red, 0-100%
6	0	255	LED Strobe speed, slow to fast

# **Technical Specifications**

• Control Mode: DMX512, RF Remote

Control Interface: 3-pin XLR

• DMX Channels: 6

Confetti Capacity: 500 gramsContinuous Output: 20-30 seconds

Firing Distance

Packed Confetti: up to 6 metresLoose Confetti: up to 3 metres

• LED: 12x 3 W RGB

• Input Voltage: 220 V AC, 50 Hz, 1,800 W

Dimensions: 270\*270\*560 mm

• Net Weight: 8 kg

# Warranty

Please refer to your local dealer or contact Event Lighting.