



SHOOTER2

Double Head Confetti Shooter

USER MANUAL



For safety, please read this user manual carefully before initial use.

Event Lighting reserves the right to revise the manual at any time. Information and specifications within this manual are subject to change without notice. Event Lighting assumes no liability or responsibility for any errors or omissions. Please consult Event Lighting for any clarification or information regarding this item.

Version: 2

Safety Instructions

Warning

- Do not open this device, there are no user-serviceable parts inside.
- Do not look at the light source when the device is on.
- This unit's housing may be hot during or after operation.
- Install this device in a location with adequate ventilation, at least 50cm (20 inches) from adjacent surfaces.
- Do not leave any flammable materials within 50cm of this unit while operating or connected to power.
- Do not operate this device outdoors or in any location where dust, excessive heat, water or humidity may affect it.
- ONLY connect this device to a grounded and protected circuit.
- ONLY use hanging bracket to carry this device

- Do not operate this device if the housing, lenses or cables appear damaged.
- Do not connect this device to dimmer or rheostat.
- In case of a serious operating problem, stop using immediately.
- The maximum ambient temperature is 104° F (40° C). Do not operate this device at higher temperatures.

RF Remote

SHOOTER2 can be controlled with an RF remote from up to 15metres away.



DMX Chart

- This fixture is controlled by the universal DMX 512 protocol. The DMX address is the first channel used to receive instructions from the external controller. For independent control, each fixture must be assigned a unique address for each of its control channels. For example, this device has one channel mode: 4, if it's set to 4 channel mode, and there are several fixtures need to be independently controlled, we just simply address first fixture at 1, and second fixture at 5, third one at 9, etc.
- If multiple fixtures have the same DMX address, they will behave synchronically.
- Display will flash when no DMX signal is received.

Channel	Function
1	Shoot Left
2	Shoot Right
3	Shoot both
4	Shoot Left to Right

Technical Specifications

- Control Mode: DMX512, RF Remote
- Control Interface: 3-pin XLR
- DMX Channels: 4
- Confetti Cartridge: 60/80cm
- Dimensions: 360x120x220 mm
- G.W.: 3.5 kg

Warranty

Please refer to your local dealer or contact Event Lighting.