

# HAVOCW19X40 MENU GUIDE

<b>CONNECT</b>	ADDRESS	FIXTURE	VALUE (1-512)(001)			
		PIXELS	VALUE (1-512)(001)			
	CONTROL PROTOCOL	FIXTURE	DMX/W-DMX			
		PIXELS	FOLLOW FIXTURE FOLLOW FIXTURE/DMX/W-DMX			
	DMX MODE	FIXTURE	BASIC/STANDARD BASIC/STANDARD/EXTENDED			
		PIXELS	OFF/RING/PIXELS			
	WIRELESS	WDMX ON/OFF	ON/OFF			
		WDMX MODE	TRANSMITTER/RECEIVER			
		TX LINK	ON/OFF			
		TX UNLINK	ON/OFF			
RX RESET		ON/OFF				
IN TO WDMX		OFF/FIX TO WDMX/PIX TO WDMX				
WDMX TO DMX		ON/OFF				
<b>SETUP</b>	FIXTURE SETTINGS	DMX FAULT	HOLD/BLACKOUT			
		TEMPERATURE UNIT	FAHRENHEIT/CELSIUS			
		FAN MODE	AUTO/HIGH/SILENT			
		DIMMER CURVE	LINEAR/S-CURVE/SQUARE LAW LINEAR/S-CURVE/SQUARE LAW/ INVERSE SQUARE LAW			
		DIMMER SPEED	AUTO/FAST/MEDIUM/SLOW			
		LED FREQUENCY	600HZ/1200 600HZ/1200 HZ/2000 HZ/4000 HZ/6000HZ/25KHZ/50KHz			
		MENU LANGUAGE	En/Fr/Sp/简/繁 (En)			
		TRANSFER CONFIGURATION	WITHOUT DMX ADDRESS WITH DMX ADDRESS			
		WHITE CALIBRATION	OFF/STUDIO			
		Tungsten emulation	ON/OFF			
		INVERT MAPPING	ON/OFF			
		MOVEMENT	PAN REVERSE	ON/OFF		
			TILT REVERSE	ON/OFF		
	PAN/TILT FEEDBACK		ON/OFF			
	PAN/TILT MODE		SLOW/MEDIUM/FAST			
	TOTEM MODE		OFF/UP/DOWN			
	SCREEN	BACKLIGHT	ON/10S/20S/30S			
		FLIP DISPLAY	ON/OFF/AUTO			

		KEY LOCK	ON/OFF			
INFORMATION	FIXTURE TIME	FIXTURE HOURS	TOTAL	( ONLY READ)		
			PARTIAL	(READ AND RESET AND RESET)		
		CURRENT HOURS	TOTAL	( ONLY READ)		
			PARTIAL	(READ AND RESET AND RESET)		
		LED HOURS	TOTAL	( ONLY READ)		
			PARTIAL	(READ AND RESET AND RESET)		
		POWER ON CYCLE	TOTAL	( ONLY READ)		
			PARTIAL	(READ AND RESET AND RESET)		
		TEMPERATURE	NEAR SOURCE TEMP, DRIVER PCB TEMP, LED PCB TEMP,...			
		FAN SPEED	NEAR SOURCE FAN, BASE FAN,...			
	CHANNEL VALUE	PAN...				
	ERROR MESSAGE	PAN, TILT...				
	FIXTURE MODEL	XXXXXXXXXX				
	RDM UID	(READ AND RESET)				
SOFTWARE VERSION	1U01 V1.0.00...					
SERVICE	RESET	ALL				
		PAN & TILT				
		...				
	CALIBRATION	PASSWORD				
		PAN				
		...				
	MANUAL CONTROL	PAN				
		...				
	RELOAD DEFAULT	BASIC RELOAD	ON/OFF			
		PROGRAM RELOAD	ON/OFF			
PASSWORD						
FACTORY RELOAD		ON/OFF				
PLAY①	DMX RECEIVE					
	SLAVE RECEIVE	SLAVE RECEIVE 1,2,3				
	SEQUENCE	MASTER / ALONE				
	MUSIC	MASTER / ALONE				

PROGRAM		MIC SENS	0%~100%		
	SELECT CHASE②	CHASE PART 1	CHASE 1 ~ 8 CHASE 1		
		CHASE PART 2	CHASE 1 ~ 8 CHASE 2		
		CHASE PART 3	CHASE 1 ~ 8 CHASE 3		
	EDIT CHASE②	CHASE 1	CHASE TEST		
		:	STEP 01		=XXX
		CHASE 8	STEP 64		=XXX
	EDIT SCENES EDIT SCENES②	EDIT SCENE 001	PAN,TILT,.....		=XXX
		~ EDIT SCENE 250	--FADE TIME--		=XXX
			--SECNE TIME--		=XXX
		DMX Input			
SCENES RECORD	ScXX=>ScXX				
FACTORY	RDM PID CODE		xxx		
	LOCKING		PASSWORD		
			xxxHOURS		
			unlocking CODE		
	CALIBRATION		PASSWORD		
			PAN		
			...		
			ZOOM		
			FOCUS		
			GOBO 1 FOCUS		FOCUS
			...		
			GOBO 8 FOCUS		FOCUS
			GOBO 1 INDEX		INDEX
			...		
			GOBO 8 INDEX		INDEX
			...		
			MAX TEMPERATURE		80~139°C/176~282°C
	Reset All Data		xxx		